

# Kite Metal Folding Chair

## For Healthcare Environments

### Cleaning Instructions



#### Crypton Fabric

Clean with a soft, damp cloth. Spots can be removed by scrubbing with a mixture of water and enzyme laundry detergent (2 cups water to 1 teaspoon detergent).

Tougher stains should be treated professionally. We do not recommend cleaning crypton with any mixture containing bleach. Note that seat and back upholstery covers can be removed for more thorough cleaning.

#### Vinyl

Clean with a soft cloth dampened with warm water and a mild soap solution. Stubborn stains and spills may be treated with a sponge or soft brush and mild non-abrasive cleanser. For best results please refer to the cleaning instructions of the relevant fabric supplier. Note that seat and back upholstery covers can be removed for more thorough cleaning.



#### Metal Frames and Wall Bracket

Dust with a soft, clean cloth. It may be necessary to use a mild non-abrasive cleaner. Do not use abrasive Ammonia-based cleaners. Mild non-abrasive cleaners should only be used occasionally.