

Prairie Case Goods

For Healthcare Environments

Cleaning Instructions



All of the surfaces listed below will withstand cleaning using a solution of 0.5 Hydrogen Peroxide (such as Virox®) or a 70% Isopropyl alcohol solution following the recommended cleaning frequency of a patient room environment as set out in such guidelines as Best Practices for Environmental Cleaning by PIDAC. When cleaning with either of the above solutions, it is a requirement that the solution not be allowed to sit for an extended time on the surface, but should be wiped thoroughly within a few moments of application.

Laminate Surfaces

Dust with a soft, clean cloth. To remove fingerprints etc. scrub with a damp soapy cloth followed by a rinse with cold water. Stubborn stains can be removed with hot water and a bit of vinegar. Avoid using abrasive cleaning tools as these may scratch the laminate surface. It may be necessary to use a mild non-abrasive cleaner.

Wood Surfaces

Wood drawer fronts are protected by a stain-resistant pre-catalyzed finish. For normal cleaning, wipe the surface with a soft, damp (not wet) cloth, with a mild detergent solution. We recommend full-strength or diluted glass cleaner products since they do not cause surface smearing or haze. A few examples of alternative cleaners include: Bleach, Hi-Tor® Plus, Sani-Master, Ammonia, Sursan, Matar®, TOR® HB, Quat Disinfectant, Virox™, and Virex® CaviWipes™. These cleaners must be used according to the manufacturer's instructions. Avoid chemical and/or abrasive cleaning compounds. We also do not recommend using brand-name furniture polishes. While they will not damage the surface, they may cause smearing and haze. Additionally, products containing silicone or wax content should be avoided for best long-term results.

Metal Drawer Components

Dust with a soft, clean cloth. It may be necessary to use a mild non-abrasive cleaner. Do not use abrasive Ammonia-based cleaners. Mild non-abrasive cleaners should only be used occasionally.

Casters (if applicable)

Casters should be regularly inspected and cleaned of debris that will impede their ability to roll and swivel.

Drawer Liners (if applicable)

Drawer liners can be removed from drawer when drawer is fully extended. Drawer liners are a seamless plastic construction and can be cleaned/disinfected using strong cleaners and abrasive cleaning tools if necessary.